


Set and Inspect for Mazak controls

Set and Inspect is a simple, intuitive, on-machine probing app for customers who require an easy-to-use probing solution.

Unlike traditional programming software, Set and Inspect is so easy to use that virtually no training is required: the software's intuitive interface guides the user through the process of creating a probing cycle, automatically generates the required machine code for the probing cycle and loads it to the control; making it perfect for new users and those with limited probing experience or machine code knowledge.



Benefits

- Simple to use, highly visual display in an intuitive, easy-to-understand design
- No probing experience or machine code knowledge necessary
- Significantly reduces data entry errors
- Allows fast and accurate part set-up
- Supports part setting, inspection, and tool setting cycles
- Compatible with a range of 3-axis and 5-axis machine tools
- Choice of programming modes: use Single cycle to manually inspect individual features; use Program builder to generate an inspection program containing multiple features that can be embedded in other routines

Part number	A-5999-1300	
Supported Mazak controls ¹	MAZATROL SmoothX and SmoothG	
Supported machine types	Horizontal machining centres, vertical machining centres, INTEGREX e-H, INTEGREX e-V, INTEGREX i-series, INTEGREX j-series, VARIAXIS	
Hard disk requirements		
App alone	45 MB	
.NET Framework	Approximately 850 MB (32-bit controls); approximately 2 GB (64-bit controls)	
Supported cycles: Single cycle (Mazak machining centres and Mazak VARIAXIS)		
Part setting/inspection	Measurement	Single surface, bore, boss, pocket, web, corner (internal), corner (external), line, 3-point plane, 5-point rectangle (internal), 5-point rectangle (external), 3-point bore, 3-point boss, 3D corner, rotary axis update
	Calibration	Traditional: XY, Z, XYZ, probe check GoProbe: XY, Z, probe check
Contact tool setting	Measurement	Length, length and diameter, multiple tools
	Calibration	Round stylus, square stylus
Non-contact tool setting	Measurement	Length, length and diameter, corner radius, broken tool, broken tool: solid tools, edge check, profile check, length: on-centre multiple tools
	Calibration	Beam alignment, beam calibration
Supported cycles: Single cycle (Mazak INTEGREX)		
Part setting/inspection	Measurement (B0 and B90, SP1 and SP2)	Single surface, bore, boss, pocket, web, 3-point bore, 3-point boss, rotary axis update, C-axis find (internal), C-axis find (external)
	Calibration	Sphere
Cross-set tool setting ²	Measurement	Milling: length, length and diameter. Turning: B0, B45
	Calibration	Calibration
Non-contact tool setting	Measurement	Length, length and diameter, corner radius, broken tool, broken tool: solid tools, edge check, profile check, length: on-centre multiple tools
	Calibration	Beam alignment, beam calibration
Supported cycles: Program builder (Mazak machining centres and Mazak VARIAXIS)		
Part setting/inspection	Measurement	Single surface, bore, boss, pocket, web, corner (internal), corner (external), line, 5-point rectangle (internal), 5-point rectangle (external), 3-point bore, 3-point boss, rotary axis update
Macro prerequisites		
Machining centres and Mazak VARIAXIS	Inspection Plus	Renishaw part no. A-4013-0112, version 0T or later
	Contact tool setting	Renishaw part no. A-4013-0133
	Non-contact tool setting	Renishaw part no. A-4013-0119
Mazak INTEGREX	Inspection Plus	Renishaw part no. A-4013-0106, version AH or later
	Cross-set tool setting ²	Renishaw part no. A-4013-0330
	Non-contact tool setting	Renishaw part no. A-4013-0123
Supported Renishaw probes	Spindle probes	MP700, OMP40-2, OMP60, OMP400, OMP600, RMP40, RMP60, RMP600, OLP40, OLP60, RLP40, Primo Radio Part Setter
	Contact tool setters	OTS, RTS, TS27R, TS34, Primo Radio 3D Tool Setter
	Non-contact tool setters	NC4
Supported languages	Czech, English, French, German, Italian, Japanese, Korean, Polish, Portuguese, Russian, Simplified Chinese, Spanish, Swedish, Thai, Traditional Chinese, Turkish	

¹ Microsoft® Windows®-based controls. Mazak API must be installed. For other controls, please contact your local Mazak office.

² Mazak INTEGREX machine tools with a horizontal Z axis only.

For worldwide contact details, visit www.renishaw.com/contact

RENISHAW HAS MADE CONSIDERABLE EFFORTS TO ENSURE THE CONTENT OF THIS DOCUMENT IS CORRECT AT THE DATE OF PUBLICATION BUT MAKES NO WARRANTIES OR REPRESENTATIONS REGARDING THE CONTENT. RENISHAW EXCLUDES LIABILITY, HOWSOEVER ARISING, FOR ANY INACCURACIES IN THIS DOCUMENT.

© 2015–2017 Renishaw plc. All rights reserved.

Renishaw reserves the right to change specifications without notice.

RENISHAW and the probe symbol used in the RENISHAW logo are registered trade marks of Renishaw plc in the United Kingdom and other countries. apply innovation and names and designations of other Renishaw products and technologies are trade marks of Renishaw plc or its subsidiaries. All other brand names and product names used in this document are trade names, trade marks or registered trade marks of their respective owners.



H - 5999 - 8200 - 05

Part no.: H-5999-8200-05-B
Issued: 03.2017